


# Capture Systems

Command and  
Control API



# Capture Systems

# Command and Control

# API

## **Capture Systems LTD.**

6 Ravnitzky St.,  
Petach-Tikva 4900617  
Israel  
Office: +972-(0)3-3038108  
Fax: +972-(0)3-6200621  
[support@capture-sys.com](mailto:support@capture-sys.com)  
[www.capture-sys.com](http://www.capture-sys.com)

Revision: 2.4.14

## Contact

For any questions, assistance and troubleshooting regarding this document please contact us at:

Web: [capture-sys.com](http://capture-sys.com)

Sales: [sales@capture-sys.com](mailto:sales@capture-sys.com)

Support: [support@capture-sys.com](mailto:support@capture-sys.com)

Phone: +972-3-3038108


## Copyright and Use Agreement

©Copyright 2019, Capture-Systems Ltd. All Rights reserved. The Capture-Systems name and logo and all related product and service names, design marks and slogans are the trademarks, and service marks of Capture-Systems Ltd.

All data, specifications, and information contained in this publication are based on information that we believe is reliable at the time of printing. Capture Systems reserves the right to make changes without prior notice.

## Alerts

The following notifications are used throughout the document to help identify important safety and setup information to the user:

 **IMPORTANT:** identifies actions that may harm the system performance. If the instructions are not clear enough in the tagged section please contact Capture support team before performing any action.

## End clause

We welcome all feedback from our customers and will appreciate any comments regarding this manual. If you find any errors while reading this manual or parts which are not clear please send us an email and we will fix the problem.

# Table of contents

<b>1 INTRODUCTION</b>	<b>9</b>
<b>2 PROTOCOL PACKET STRUCTURE</b>	<b>10</b>
2.1 PACKET STRUCTURE	10
2.2 REPLY PACKET STRUCTURE	12
2.2.1 Ack / Nack Reply	12
2.2.2 Data Reply	13
<b>3 COMMANDS DESCRIPTION</b>	<b>14</b>
<b>4 COMMANDS</b>	<b>15</b>
4.1 GET DATA COMMANDS	15
4.1.1 MOT_MerRegister	15
4.1.2 MOT_DerRegister	15
4.1.3 MOT_SrhRegister	15
4.1.4 MOT_SrlRegister	15
4.1.5 MOT_MsrRegister	16
4.1.6 MOT_GetMotorCurrent	16
4.1.7 MOT_GetMotorVoltage	16
4.1.8 MOT_GetMotorPosition	16
4.1.9 MOT_GetLoadPosition	17
4.1.10 MOT_GetMotorSpeed	17
4.2 SET DATA COMMANDS	17
4.2.1 MOT_SetAcceleration	17
4.2.2 MOT_SetSpeed	17
4.2.3 MOT_SendPosition	18
4.2.4 MOT_Update	18
4.2.5 MOT_Homing	18
4.2.6 MOT_SetPositionRelative	19
4.2.7 MOT_SetPositionAbsolute	19
4.2.8 MOT_SetSpeedMode	19
4.2.9 MOT_SetPositionMode	20
4.2.10 MOT_AxisOn	20
4.2.11 MOT_AxisOff	20
4.2.12 MOT_AxisReset	21
4.2.13 MOT_SetTum	21
4.2.14 MOT_ResetFaults	21
4.2.15 MOT_SetShortPath	22
4.2.16 MOT_GetShortPath	22
4.2.17 MOT_SetMotionComplete	22
4.3 SCANNING COMMANDS	23
4.3.1 SCN_SetYawMin	24
4.3.2 SCN_SetYawMax	24
4.3.3 SCN_SetPitchMin	24
4.3.4 SCN_SetNumSteps	25
4.3.5 SCN_SetStepHeight	25
4.3.6 SCN_SetScanSpeed	25
4.3.7 SCN_SetShortPath	26
4.3.8 SCN_IsScanOn	26
4.3.9 SCN_StopScan	26
4.3.10 SCN_StartScanZigZag	27
4.3.11 SCN_StartScanSnake	27

4.3.12	<i>SCN_StartScanSquare</i>	27
4.3.13	<i>SCN Operation Notes</i>	28
4.4	GPS COMMANDS	29
4.4.1	<i>GPS_GetHeading</i>	29
4.4.2	<i>GPS_GetLatitude</i>	29
4.4.3	<i>GPS_GetLongitude</i>	29
4.4.4	<i>GPS_GetAltitude</i>	30
4.4.5	<i>GPS_GetNorthing</i>	30
4.4.6	<i>GPS_GetEasting</i>	30
4.4.7	<i>GPS_GetZone</i>	30
4.4.8	<i>GPS_PositionReady</i>	31
4.4.9	<i>GPS_HeadingReady</i>	31
4.4.10	<i>GPS_isConnectedGPS</i>	31
4.4.11	<i>GPS_GetTargetLLA</i>	31
4.4.12	<i>GPS_SetTargetLLA</i>	32
4.4.13	<i>GPS_GetTargetUTM</i>	32
4.4.14	<i>GPS_SetTargetUTM</i>	32
4.4.15	<i>GPS_GoToTarget</i>	33
4.4.16	<i>GPS_ClearAllTargets</i>	33
4.5	IMU COMMANDS	34
4.5.1	<i>IMU_IsReadyImu</i>	34
4.5.2	<i>IMU_GetRoll</i>	34
4.5.3	<i>IMU_GetPitch</i>	34
4.5.4	<i>IMU_GetYaw</i>	35
4.6	COMMUNICATION COMMANDS	36
4.6.1	<i>COM_Reboot</i>	36
4.6.2	<i>COM_Connect</i>	36
4.6.3	<i>COM_Disconnect</i>	36
4.6.4	<i>COM_SetComType</i>	37
4.6.5	<i>COM_GetPn</i>	37
4.6.6	<i>COM_GetSn</i>	37
4.6.7	<i>COM_GetFw</i>	37
4.6.8	<i>COM_GetHw</i>	38
4.7	IP CHANGE COMMANDS	39
4.7.1	<i>IP_SetControllerIP</i>	39
4.7.2	<i>IP_GetControllerIP</i>	39
4.7.3	<i>IP_SetControllerPort</i>	40
4.7.4	<i>IP_GetControllerPort</i>	40
4.7.5	<i>IP_SetControllerSubnetMask</i>	40
4.7.6	<i>IP_GetControllerSubnetMask</i>	40
4.7.7	<i>IP_SaveIP</i>	41
4.8	STABILIZATION COMMANDS	42
4.8.1	<i>STB_StabilizationOn</i>	42
4.8.2	<i>STB_StabilizationOff</i>	42
4.8.3	<i>STB_StabMoveRel</i>	42
4.8.4	<i>STB_StabMoveAbs</i>	43
4.8.5	<i>STB_SetStabSpeed</i>	43
4.8.6	<i>STB_StabSpeedOn</i>	43
4.8.7	<i>STB_StabSpeedOff</i>	44
4.8.8	<i>STB Operation Notes</i>	44
4.9	PRESET COMMANDS	45
4.9.1	<i>PRST_GetPreset</i>	45
4.9.2	<i>PRST_SetPreset</i>	45
4.9.3	<i>PRST_GoToPreset</i>	45
4.9.4	<i>PRST_ClearAll</i>	45

4.9.5	<i>PRST_GetPresetFlag</i>	46
4.9.6	<i>PRST_ClearSinglePreset</i>	46
4.10	ERROR CONTROL COMMANDS	47
4.10.1	<i>ERR_MotionErrorRegister</i>	47
4.10.2	<i>ERR_DetailedErrorRegister</i>	49
4.10.3	<i>ERR_StatusRegisterHigh</i>	50
4.10.4	<i>ERR_StatusRegisterLow</i>	51
4.10.5	<i>ERR_MotionStatusRegister</i>	51
4.10.6	<i>ERR_CaptureMotorErrorRegister</i>	52
4.10.7	<i>ERR_CaptureSystemRegister</i>	53
4.10.8	<i>ERR_ClearErrors</i>	54
4.10.9	<i>ERR_GetMotorErrorString</i>	54
4.10.10	<i>ERR_GetSystemErrorString</i>	54
4.10.11	<i>ERR_GetLoadImuErrorString</i>	54
4.10.12	<i>ERR_GetBaselmuErrorString</i>	55
4.10.13	<i>ERR_GetGpsComErrorString</i>	55
4.10.14	<i>ERR_GetGpsPosString</i>	55
4.10.15	<i>ERR_GetGpsHeadErrorString</i>	56
4.10.16	<i>ERR_GetProtocolErrorString</i>	56
4.10.17	<i>Error messages description:</i>	57
4.11	VIDEO TRACKING COMMANDS	58
4.11.1	<i>VDT_GetImageSize</i>	58
4.11.2	<i>VDT_SetTrackMode</i>	58
4.11.3	<i>VDT_GetTrackMode</i>	58
4.11.4	<i>VDT_SetPtControlMode</i>	59
4.11.5	<i>VDT_GetPtControlMode</i>	59
4.11.6	<i>VDT_SetLatitude</i>	59
4.11.7	<i>VDT_GetLatitude</i>	60
4.11.8	<i>VDT_SetLongitude</i>	60
4.11.9	<i>VDT_GetLongitude</i>	60
4.11.10	<i>VDT_SetAltitude</i>	61
4.11.11	<i>VDT_GetAltitude</i>	61
4.11.12	<i>VDT_GetHeading</i>	61
4.11.13	<i>VDT_GetTrackError</i>	61
4.11.14	<i>VDT_VideoStabilization</i>	62
4.11.15	<i>VDT_StartTrackXy</i>	62
4.11.16	<i>VDT_GoToLlaTarget</i>	62
4.11.17	<i>VDT_SetHeading</i>	63
4.11.18	<i>VDT_GetTargetsList</i>	63
4.11.19	<i>VDT_StartTrackTargetIndex</i>	63
4.11.20	<i>VDT_StopTrack</i>	63
4.11.21	<i>VDT_SetAcquisitionAssist</i>	64
4.11.22	<i>VDT_GetAcquisitionAssist</i>	64
4.11.23	<i>VDT_SetIntelligentAssist</i>	64
4.11.24	<i>VDT_GetIntelligentAssist</i>	65
4.11.25	<i>VDT_TargetDetectionOn</i>	65
4.11.26	<i>VDT_TargetDetectionOff</i>	65
4.11.27	<i>VDT_SetCrossType</i>	66
4.11.28	<i>VDT Operation Notes</i>	66
<b>5</b>	<b>APPENDIX</b>	<b>67</b>
5.1	DATA FORMATS	67
5.1.1	<i>Floating point 32-bit format example</i>	67
5.1.2	<i>Double precision 64-bit format example</i>	67
5.1.3	<i>Target packet format LLA</i>	67

5.1.4	Target packet format UTM	68
5.1.5	Preset packet format	68
5.1.6	Targets list format	68
<b>6</b>	<b>COMMUNICATION SETTINGS</b>	<b>69</b>
6.1	DEFAULT VALUES FOR ETHERNET:	69
6.2	DEFAULT VALUES FOR SERIAL PORTS:	70
<b>7</b>	<b>PACKET SEND/RECEIVE EXAMPLES</b>	<b>71</b>
7.1	MOT MOTION EXAMPLE	72
7.2	GET DATA COMMANDS	73

## Revision History

Revision	Date	Changes
2.4.14	1/12/19	Data removed in MOT_Homing command.
2.4.13	27/10/19	Packet reply notes added. Video tracking working procedure added.
2.4.12	8/9/19	Preset structure changed. Video and Stabilization command notes added. Motor short path command added.
2.4.11	3/9/19	Typo in Error control section
2.4.10	10/7/19	Registers ICD merging
2.4.9	4/7/19	Added reply packet structure
2.4.8	1/7/19	Supported tracking modes changed, added acquisition assist, intelligent assist and detection support, set cross types
2.4.7	29/4/19	Added video tracking commands and target list format example, Preset commands added
2.4.6	4/19	Video tracking commands – initial release
2.4.5	5/8/18	Added communication commands
2.4.4	21/5/18	Document design changed, protocol description, scanning description, communication settings (chapter 6)
2.4.3	3/4/18	Typo fixes
2.4.0	13/2/18	Minor design changes, multiple scanning types added
2.3.1	1/1/18	Added GPS support, added motor packets examples
2.3	7/11/17	Packet structure description
1.0	5/6/17	Initial release



# 1 Introduction

The purpose of this document is to explain how to use the Capture systems protocol in the easiest way. The protocol has several types of commands and there are examples for each type of command. Capture pedestals communication protocol describes the messages structure in order to communicate with the system's internal controller.

Our systems have three types of control levels: Manual, Stabilized and Tracker.

With this protocol the user is presented with a collection of commands which allow for an implementation of motion control applications over the pedestal system.

Communication with the system can be made by the following protocols:

- Ethernet – TCP (default)
- Serial RS-232
- Serial RS-422
- Serial RS-485

Remark: Your specific communication implementation should be mentioned in your order documents.

All packets in the protocol are the same for all communication types. The only difference is in the connection procedure and will be cleared further ahead.

Manual system will allow the user to control all axes in terms of motion profile (acceleration, speed, position, etc...) and retrieve data regarding the status of the motors (voltage, current motor position, etc...). Stabilized and Tracker systems will allow the user an extended control of the system and its components as described in the following table.

Feature	Manual	Stabilized	Tracker	Video
<b>Speed mode motion profile</b>	✓	✓	✓	✓
<b>Position mode motion profile Absolute/Relative</b>	✓	✓	✓	✓
<b>Automatic scanning patterns</b>	Dual axis system only	✓	✓	✓
<b>Presets for desired fixed points of interest</b>	Dual axis systems only	✓	✓	✓
<b>Readings of Real-Time motion parameters</b>	✓	✓	✓	✓
<b>Orientation data about the system (Euler angles)</b>		✓	✓	✓
<b>Ability to stabilize the system on a certain position</b>		✓	✓	✓
<b>Movement under stabilization in all modes</b>		✓	✓	✓
<b>Self GPS position and heading (UTM or LLA)</b>			✓	✓
<b>Presets with datum-points of targets</b>			✓	✓
<b>Automatic aim the system on a GPS point</b>			✓	✓
<b>Video Tracking</b>				✓

- Stabilized, Tracker and Video systems are not supported for single axis pedestals.

## 2 Protocol packet structure

---

Protocol packet structure was chosen to enable sending and receiving of message between the user and the system in the easiest way. There are three parts for each packet in the protocol: Header, Data and Check Sum.

### **Header:**

Indicate the start of the packet with the destination of the packet and the OpCode of the command.

### **Data:**

Data being sent in both directions, PC <=> Controller.

Protocol messages can be with or without data.

The data field can have the following data format:

- Double precision 64-bit (8 bytes).
- Floating point 32-bit (4 bytes).
- Unsigned Int 32-bit (UInt32) (4 bytes)
- Unsigned Int 16-bit (UInt16) (2 bytes)
- Unsigned/signed Int 8-bit (UInt8/Int8) (1 byte)
- ASCII string (Data length varies according to the string).

### **Check Sum:**

Summation of all the bytes in the packet except the two Start Bytes and the Check Sum byte.

### 2.1 Packet Structure

Start Byte 1	Start Byte 2	Length	Group ID	Axis ID	OpCode High	OpCode Low	Data 1	Data 2	...	Data N	Check Sum
--------------------	--------------------	--------	-------------	------------	----------------	---------------	-----------	-----------	-----	-----------	--------------

*Table 1 - Capture Packet Structure*

Start Bytes are fixed for every message, they indicate the start of the packet.

**Start Byte 1:** 0x50.

**Start Byte 2:** 0x54.

**Length:** This byte indicates the total number of bytes in the packet minus the Start Bytes, Length and Check Sum,

e.g. for messages without data Length is 0x04, for messages with 4 bytes of data Length is 0x08.

**Group ID:** Regarding system with multiple pedestal units only. Group ID specifies the pedestal unit which the current message is addressed to. For single pedestal system, this field should be set to 0x00.

**Axis ID:** This byte specifies which axis the information is sent to. 0x01 is for Yaw, 0x02 is for Pitch and 0x03 is for Roll.

All the commands regarding the motors require Axis ID in order to send the command to the correct destination.

**OpCode High:** In the Capture Protocol the OpCode is represented by 2 bytes (16-bit) as 4 Hex digits. The OpCode High byte is the first byte (or first two Hex digits).

**OpCode Low:** The OpCode Low byte is the last byte (or last two Hex digits).

*Example:*

The command MOT\_SendPosition has the OpCode of 0x0132, so in this case the OpCode High will be 0x01 and the OpCode Low will be 0x32.

**Data:** These bytes are present only in case when data is included in the packet. The controller/user can send packet with or without data (depending on the command). Data type is specified in the protocol for each command.

Data 1 (first byte in order) is always the MSB (most significant byte).

Length byte is determined by the number of data bytes + 4.

**Check Sum:** This byte is used for error detection, it is the summation remainder (lowest byte in case of overflow) of all the bytes (Hex format) in the packet except the two Start Bytes and the Check Sum.

Check Sum Example:

Sending MOT\_GetMotorVoltage message to Axis 1 (Yaw) with OpCode 0x0107:

Start Byte 1	Start Byte 2	Length	Group ID	Axis ID	OpCode High	OpCode Low	Check Sum
0x50	0x54	0x04	0x00	0x01	0x01	0x07	0x0D

*Table 2 - Example for MOT\_GetMotorVoltage message*

The Check sum Byte is calculated in Hex as:  $0x04+0x01+0x01+0x07 = 0x0D$ .

Pay attention to the structure of this message, the data bytes are missing. This is the correct way to send a packet without data. Length byte is 0x04 thus the controller knows that this message has no data. When the Controller receives the packet, it checks if the Check Sum byte matches the content of the packet. If the checksum test fails, the controller will send Not ACK byte (0xF6) so that the user know there was something wrong while sending that packet.

When the check sum is correct, the controller will execute the command. After the controller is done, it will sent confirm that the message was received correctly. For commands that don't have return data from the controller, there will be an ACK byte sent from the controller – 1 byte of 0x06. In case there is return data the answer packet will be sent without ACK.

When the controller sends back a packet with data, the OpCode will be the same as the one being sent by the user.

For Example in the response packet for the MOT\_GetMotorVoltage command the OpCode High is 0x01 and OpCode Low is 0x07.

Returning value of 24.12 for MOT\_GetMotorVoltage at Yaw axis will be as follows:

Start Byte 1	Start Byte 2	Length	Group ID	Axis ID	OpCode High	OpCode Low	Data 1	Data 2	Data 3	Data 4	Check Sum
0x50	0x54	0x08	0x00	0x01	0x01	0x07	0x41	0xC0	0xF5	0xC3	0xCA

Table 3 - Example for MOT\_GetMotorVoltage return message

## 2.2 Reply Packet Structure

The protocol has two types of reply packets.

- Ack / Nack reply.
- Data reply.

### 2.2.1 Ack / Nack Reply

The packet structure of Ack/Nack reply contains a single byte. This byte value indicates the last packet state.

Reply	Byte	Title	Description	Operation
Ack	0x06	Acknowledge	The command is valid and have current checksum	None
Nack	0x16	Pedestal Unavailable	The motor controllers are unavailable for some reason.	Power cycle. If the error remains, please contact Capture support team.
Nack	0x76	Video Tracker Unavailable	The video tracker is not available for some reason. *	Power cycle. If the error remains, please contact Capture support team.
Nack	0xA6	Invalid Command	The controller can't handle the command with the current configuration.	Verify that the current command is valid with your system configuration according to Capture API. e.g. you can't send stabilization commands for manual system and this behavior will cause sending reply of 0xA6
Nack	0xB6	Invalid Motor Checksum	There is an error in the communication line between the Cap-Track controller to the motor controllers.	Power cycle. If the error remains, please contact Capture support team.
Nack	0xE6	Execution Error	General executing error of the command.	Power cycle. If the error remains, please contact Capture support team.
Nack	0xF6	Wrong Checksum	The user sent a packet with wrong checksum.	Verify the checksum calculations of the packet.

- Relevant only for systems that includes video tracker.

## 2.2.2 Data Reply

Protocol reply packet structure was chosen to enable receiving data from the system in the easiest way. In this case, the reply packet structure is as same as the sending packet structure and also includes the asked data in the data part of the packet.

The fields that might change between the sending packets to the reply packet are the Length, Data and Checksum.

The following example will demonstrate the implementation of a single command that retrieve data from the controller:

User send: *IMU\_GetRoll (message without data)*

0x50	0x54	0x04	0x00	0x00	0x06	0x02	0x0C
------	------	------	------	------	------	------	------

Controller answer: *return packet with data (value of 30.184 degrees, 0x41F178D5 in hex)*

0x50	0x54	0x08	0x00	0x00	0x06	0x02	0x41	0xF1	0x78	0xD5	0x8F
------	------	------	------	------	------	------	------	------	------	------	------

Marked in blue are the static fields of the packets.

Marked in orange are the changeable fields that changed according to the user request (in this case *IMU\_GetRoll*).

## 3 Commands Description

---

Capture commands are categorized into several groups, while each group defines a related set of commands. The groups are:

### **COM\_commands:**

Communication commands, for establishing communication with the system controller.

### **MOT\_commands:**

- Get Data - retrieve information about the motors current status.
- Set Data – send commands to determine the desired behavior of the motors.

Both Get Data and Set Data require specifying the axis destination.

Yaw is axis No. 1, Pitch is axis No. 2 and Roll is axis No. 3. 0x01, 0x02 and 0x03 in hex.

### **SCN\_commands:**

Commands for controlling the scanning modes, setting all the scanning parameters, starting and stopping the scan.

### **IMU\_commands:**

For stabilized and tracker systems only. Retrieve system orientation in Euler angles format.

### **STB\_commands:**

Activating and stopping the stabilization mechanism of the system as well as moving under stabilization mode.

### **GPS\_commands:**

For tracker systems only. Retrieve information about the system GPS position, send/receive targets and track targets in stabilization mode.

### **IP\_commands:**

Changing the unit IP address when needed. Take extreme precaution when using these commands and read the example before implementing the IP change. (Ethernet TCP communication only)

### **PRST\_command:**

Presets are predefined points that can be saved in the controller memory.

### **VDT\_Commands:**

For video tracking applications only, activate the video tracking mechanism and retrieve tracking information.

## 4 Commands

---

### 4.1 Get data commands

#### 4.1.1 MOT\_MerRegister

<b>OpCode</b>	<b>0x0101</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Motion Error Register.

#### 4.1.2 MOT\_DerRegister

<b>OpCode</b>	<b>0x0102</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Detailed Motion Error Register.

#### 4.1.3 MOT\_SrhRegister

<b>OpCode</b>	<b>0x0103</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Motion Status Register High.

#### 4.1.4 MOT\_SrlRegister

<b>OpCode</b>	<b>0x0104</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Motion Status Register Low.

#### 4.1.5 MOT\_MsrRegister

<b>OpCode</b>	<b>0x0105</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Motion Status Register.

**Remark:** Information about the registers can be found in a separate file called 'Capture Control Panel Registers'.

#### 4.1.6 MOT\_GetMotorCurrent

<b>OpCode</b>	<b>0x0106</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	milli-Amps
<b>Description</b>	Get the actual motor current.

#### 4.1.7 MOT\_GetMotorVoltage

<b>OpCode</b>	<b>0x0107</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Voltage
<b>Description</b>	Get the actual motor voltage.

#### 4.1.8 MOT\_GetMotorPosition

<b>OpCode</b>	<b>0x0108</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the actual motor position before Gear Ratio.



#### 4.1.9 MOT\_GetLoadPosition

<b>OpCode</b>	<b>0x0109</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the actual load position after Gear Ratio.

#### 4.1.10 MOT\_GetMotorSpeed

<b>OpCode</b>	<b>0x010A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees/Sec
<b>Description</b>	Get the actual load speed.

## 4.2 Set data Commands

#### 4.2.1 MOT\_SetAcceleration

<b>OpCode</b>	<b>0x0130</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees/Sec <sup>2</sup>
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the motor acceleration.

#### 4.2.2 MOT\_SetSpeed

<b>OpCode</b>	<b>0x0131</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees/Sec
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the motor speed.

*Remark:* After sending Acceleration and Speed, the value remains in the system. Another command is needed only if there is a need to change those values.

#### 4.2.3 MOT\_SendPosition

<b>OpCode</b>	<b>0x0132</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send the desired amount of movement to the motor.

*Remark:* Position command (with the last given speed and acceleration) will be executed only after a MOT\_Update command.

#### 4.2.4 MOT\_Update

<b>OpCode</b>	<b>0x0134</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Update (Execute) the current motion set.

*Remark:* After a MOT\_Update command, the specified motor will execute the current motion profile using the last motion related commands.

These commands include:

MOT\_SetAcceleration, MOT\_SetSpeed, MOT\_SendPosition , MotionComplete, etc...

#### 4.2.5 MOT\_Homing

<b>OpCode</b>	<b>0x0135</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Activating Homing mode that is stored on each motor memory.

#### 4.2.6 MOT\_SetPositionRelative

<b>OpCode</b>	<b>0x0138</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Setting the position commands to be relative.

*Remark:* In Relative Mode, the position commands will be added to the current position.

#### 4.2.7 MOT\_SetPositionAbsolute

<b>OpCode</b>	<b>0x0139</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Setting the position commands to be absolute.

*Remark:* In Absolute Mode, the position commands will result an absolute movement of the motor. The motor will move until the position of the motor will be as mentioned in the data sent with the current command.

#### 4.2.8 MOT\_SetSpeedMode

<b>OpCode</b>	<b>0x013A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Setting motor to speed mode operation.

*Remark:* In Speed mode, the motor will rotate in a constant speed after receiving a MOT\_SetSpeed command followed by a MOT\_Update command. The motor will keep on rotating in the given speed until it receives different speed (can be zero speed in order to stop the motor) or until a MOT\_SetPositionMode is received.

#### 4.2.9 MOT\_SetPositionMode

<b>OpCode</b>	<b>0x013B</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Setting motor to position mode operation.

*Remark:* In position mode, in order to get the motor to rotate, a MOT\_SendPosition command must be sent followed by a MOT\_Update command.

#### 4.2.10 MOT\_AxisOn

<b>OpCode</b>	<b>0x013C</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turn on the motor.

*Remark:* Turn on the power supply to the motor.

If the controller buffer had a motion command when turning off the motor with MOT\_AxisOff, the controller will return to the last command and execute it after the MOT\_AxisOn command is received.

#### 4.2.11 MOT\_AxisOff

<b>OpCode</b>	<b>0x013D</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turn off the motor.

*Remark:* Turn off the power supply to the motor.

If the motor is currently in motion during the time MOT\_AxisOff command is received the motion will stop, but the controller still remembers this last motion command and will continue from where it stopped when MOT\_AxisOn is received.

#### 4.2.12 MOT\_AxisReset

<b>OpCode</b>	<b>0x013E</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Reset the current axis.

*Remark:* Resets the Axis and restore previous configurations. When resetting, the axis will perform its homing sequence.

After this command, halt all commands for the specific axis for at least 3 seconds in order to avoid communication errors.

#### 4.2.13 MOT\_SetTum

<b>OpCode</b>	<b>0x013F</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Update the motion profile parameters.

*Remark:* Target Update Mode, build a new motion profile (with acceleration, speed and position) from scratch each time a MOT\_Update command is sent. When not sending this command, the motion profile will use the last parameters. In some cases the motor will not move properly if this command is missing from the motion commands before sending MOT\_Update command. It is advisable to send this command before each command session.

#### 4.2.14 MOT\_ResetFaults

<b>OpCode</b>	<b>0x0143</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Reset register faults of the desired axis

#### 4.2.15 MOT\_SetShortPath

<b>OpCode</b>	<b>0x014E</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Number
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the parameter of short path for the system motion.

*Remark: This command sets a short path for motion in the horizontal axis. When the value is set to 1 the horizontal movement will be the smaller difference between the current location and the target location, when set to 0 the movement will be the larger difference between them.*

#### 4.2.16 MOT\_GetShortPath

<b>OpCode</b>	<b>0x014F</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-8
<b>Data return unit</b>	Number
<b>Description</b>	Gets the parameter of short path for the system motion.

#### 4.2.17 MOT\_SetMotionComplete

<b>OpCode</b>	<b>0x0144</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Puts the current command in Motion-Complete mode.

*Remark: Sending this command will cause the motor driver to wait until the current position command has ended before executing a new one.*

*This command needs to be sent for each position command separately (before MOT\_Update).*

*Example:*

*Sending two MOT\_SendPosition with Motion complete, first with +20 degrees and second with -15 degrees will cause the motor to finish the +20 degrees and then move -15 degrees.*

### 4.3 Scanning Commands

Capture's dual axis systems supports several automatic scanning modes. The scanning modes are:

- **Zig-Zag**

While activating the Zig-Zag scanning mode the system will run the following sequence:

- Set the system to the initial position that declared by YawMin and PitchMin variables.
- Run the system in both axes to the (YawMax, StepHeight) position with the speed declared by SetScanSpeed.
- Repeat this step according to the NumSteps declaration.
- After the scan pattern is finished (reaches its higher position) the system will reverse the scan pattern and so on until the user will stop the scan manually.



- **Snake**

While activating the Snake scanning mode the system will run the following sequence:


- Set the system to the initial position that declared by YawMin and PitchMin variables.
- Run the Yaw axis to the YawMax position.
- Raise the Pitch axis with the StepHeight value.
- Run the Yaw axis back to the YawMin value.
- Raise the Pitch axis with the StepHeight value.
- Repeat those steps until the system reach the (YawMax, NumSteps \* StepHeight) position and then run back to the start position.



- **Square**

While activating the Square scanning mode the system will run the following sequence:

- Set the system to the initial position that declared by YawMin and PitchMin variables.
- Run the Yaw axis to the YawMax position.
- Run the Pitch axis to the max Pitch position that calculates by multiplying the SetpHeight and NumSteps variables.
- Run the Yaw axis to the initial Yaw position.
- Run the Pitch axis to the PitchMin minus StepHeight value.
- Run the Yaw axis to the PitchMax minus StepHeight value.
- Repeat those steps until the system reach the center of the square (according to the NumSteps value) and then reverse to the initial position.



All parameters for the scan area and speed must be sent before starting first scan.

Default values, for all of those parameters, when the program starts are 0.

All parameters must be set before each scan to make sure that the system will perform the desired scanning pattern. All scanning command needs to be send to axis number 0x00.

When the system is in scanning mode, the only motor commands that are allowed to be sent are:

MOT\_GetMotorSpeed and MOT\_GetLoadPosition. Any other motor command will be blocked by the

controller, and the user will receive not valid ACK byte (0xA6).

#### 4.3.1 SCN\_SetYawMin

<b>OpCode</b>	<b>0x0400</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the left corner of the scan area.

*Remark:* The value set is according to the position of the motor which is read by the MOT\_GetMotorPosition command.

*Example:* If MOT\_GetMotorPosition return 40 degrees, then setting SCN\_YawMin to 50 degrees will result 10 degree rotation clockwise for the scan starting point.

#### 4.3.2 SCN\_SetYawMax

<b>OpCode</b>	<b>0x0401</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the right corner of the scan area.

#### 4.3.3 SCN\_SetPitchMin

<b>OpCode</b>	<b>0x0402</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the bottom side of the scan area.

*Remark:* The value set is according to the position of the motor which is read by the MOT\_GetMotorPosition command.

*Example:* If MOT\_GetMotorPosition return 0 degrees, then setting SCN\_PitchMin to 5 degrees will result 5 degree rotation upwards for the scan starting point.



#### 4.3.4 SCN\_SetNumSteps

<b>OpCode</b>	<b>0x0403</b>
<b>Data send format</b>	Unsigned Integer (8-bit)
<b>Data send unit</b>	Integer Number
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the amount of steps from bottom to the top of the scan area.

*Remark:* One step is a movement from SCN\_YawMin to SCN\_YawMax with height in the Pitch axis set by the SCN\_SetScanStep command. This command relevant for ZigZag and Snake scans only.

#### 4.3.5 SCN\_SetStepHeight

<b>OpCode</b>	<b>0x0404</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the height of 1 step for each scan loop.

*Remark:* This parameter will determine the distance between each loop of the scan. Relevant for all types of scans.

#### 4.3.6 SCN\_SetScanSpeed

<b>OpCode</b>	<b>0x0405</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees/Sec
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the speed for the scan.

*Remark:* This parameter is relevant for all scans. Sets the speed for the horizontal (Yaw) axis for all scans. Vertical (Pitch) speed is calculated according to the scan type.

#### 4.3.7 SCN\_SetShortPath

<b>OpCode</b>	<b>0x0406</b>
<b>Data send format</b>	Single byte (value of 0 or 1)
<b>Data send unit</b>	Boolean
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set parameter of short path for the scanning.

*Remark:* This command sets a short path for scanning in the horizontal axis. When the value is set to 1 the horizontal movement will be the smaller difference between SCN\_SetYawMax and SCN\_SetYawMin, when set to 0 the movement will be the larger difference between them.

#### 4.3.8 SCN\_IsScanOn

<b>OpCode</b>	<b>0x0407</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Boolean
<b>Description</b>	Ask the controller if it is in scanning mode.

*Remark:* Return value is 1 if the controller is in scan mode, and 0 if not.

#### 4.3.9 SCN\_StopScan

<b>OpCode</b>	<b>0x0408</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Stop the motors immediately and exit scan mode.

*Remark:* This command stops both motors immediately and the controller exits scanning mode. Stop scan can take up to 500 millisecond before sending ACK and handle new incoming commands.

#### 4.3.10 SCN\_StartScanZigZag

<b>OpCode</b>	<b>0x040C</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start scan in ZigZag pattern with the given parameters.

*Remark:* When SCN\_StartScanZigZag is sent, the motors will go to the bottom left corner of the scan area and then start the scan in a ZigZag pattern.

#### 4.3.11 SCN\_StartScanSnake

<b>OpCode</b>	<b>0x040D</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start scan in Snake pattern with the given parameters.

*Remark:* When SCN\_StartScanSnake is sent, the motors will go to the bottom left corner of the scan area and then start the scan in a Snake pattern.

#### 4.3.12 SCN\_StartScanSquare

<b>OpCode</b>	<b>0x040E</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start scan in square pattern with the given parameters.

*Remark:* When SCN\_StartScanSquare is sent, the motors will go to the bottom left corner of the scan area and then start the scan in a Square pattern.

#### 4.3.13 SCN Operation Notes

This section doesn't include an operation code of a specific command. Here we explain some operation behaviours regarding the scanning mechanism.

4.3.13.1 While scanning is active (after activating opcode 0x040C-0x040E) the controller enters to scanning mode. During this mode the controller can receive only several 'Get' commands (that will be described in the next paragraph) and 'StopScan' command (opcode 0x0408). In any case that the user sends a command that is not described here the controller will return an invalid command error: **0xA6**.

The commands that the user can send during scanning are:

OpCode	Command Name
<b>0x0801</b>	STB_StabilizationOff
<b>0x0101 - 0x010A</b>	Chapter 4.1 'Get data commands'
<b>0x0E01 - 0x0E0B</b>	Chapter 4.10 'Error control commands'

## 4.4 GPS Commands

These commands retrieve data from the GPS unit (relevant to Tracker systems only).  
In all of GPS commands, the axis byte in the packet is ignored (can be sent as 0x00).

### 4.4.1 GPS\_GetHeading

<b>OpCode</b>	<b>0x0502</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the current heading given by the GPS module.

*Remark:* The heading value indicates what is the angle between earth's North Pole and the azimuth (Yaw) pointing direction.

### 4.4.2 GPS\_GetLatitude

<b>OpCode</b>	<b>0x0503</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Degrees & Decimal minutes
<b>Description</b>	Get the current latitude given by the GPS module.

*Remark:* The value is positive for the upper side of the latitude lines (North) and negative for the lower side (South).

### 4.4.3 GPS\_GetLongitude

<b>OpCode</b>	<b>0x0504</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Degrees & Decimal minutes
<b>Description</b>	Get the current longitude given by the GPS module.

*Remark:* The value is positive for the East side of the latitude lines and negative for the West side.

Both Latitude and Longitude in the format of DDMM.mmmm  
DD: degrees, MM.mmmm: decimal minutes.

#### 4.4.4 GPS\_GetAltitude

<b>OpCode</b>	<b>0x0505</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Meters
<b>Description</b>	Get the current altitude given by the GPS module.

*Remark:* The given value is the height of the system above sea level in Meters.

#### 4.4.5 GPS\_GetNorthing

<b>OpCode</b>	<b>0x0506</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Meters
<b>Description</b>	Get the current UTM Northing value given by the GPS module.

#### 4.4.6 GPS\_GetEasting

<b>OpCode</b>	<b>0x0507</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Meters
<b>Description</b>	Get the current UTM Easting value given by the GPS module.

#### 4.4.7 GPS\_GetZone

<b>OpCode</b>	<b>0x0508</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Int 8-bit.
<b>Data return unit</b>	Meters
<b>Description</b>	Get the current UTM Zone value given by the GPS module.

*Remark:* UTM Zone given by the GPS module parsed as follows:  
Positive value for Northern Hemisphere, Negative value for Southern Hemisphere.

#### 4.4.8 GPS\_PositionReady

<b>OpCode</b>	<b>0x050A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (8-bit)
<b>Data return unit</b>	Boolean
<b>Description</b>	Check if there is a valid position lock from GPS

*Remark:* this command return 1 if the values for position are valid or 0 if they are not valid.

#### 4.4.9 GPS\_HeadingReady

<b>OpCode</b>	<b>0x050B</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (8-bit)
<b>Data return unit</b>	Boolean
<b>Description</b>	Check if there is a valid heading from GPS

*Remark:* this command return 1 if the values for heading are valid or 0 if they are not valid.

#### 4.4.10 GPS\_isConnectedGPS

<b>OpCode</b>	<b>0x050C</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (8-bit)
<b>Data return unit</b>	Boolean
<b>Description</b>	Check if the system had communication since boot.

*Remark:* this command return 1 if there was a signal from the GPS since the system has started and 0 if there was no communication at all since system startup.

#### 4.4.11 GPS\_GetTargetLLA

<b>OpCode</b>	<b>0x050F</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	TargetLLA format (See section <a href="#">5.1.3</a> )
<b>Data return unit</b>	GPS Target
<b>Description</b>	Read target in LLA format. (target number between 1-15)

*Remark:* the target number is set in the Axis byte of the packet. The controller can hold up to 15 targets.

#### 4.4.12 GPS\_SetTargetLLA

<b>OpCode</b>	<b>0x0510</b>
<b>Data send format</b>	None
<b>Data send unit</b>	TargetLLA format (See section <a href="#">5.1.3</a> )
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send target in LLA format. (targets number between 1-15)

*Remark:* the target number is set in the Axis byte of the packet. The controller can hold up to 15 targets.

#### 4.4.13 GPS\_GetTargetUTM

<b>OpCode</b>	<b>0x0511</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	TargetUTM format (See section <a href="#">5.1.4</a> )
<b>Data return unit</b>	GPS Target
<b>Description</b>	Read target in UTM format. (target number between 1-15)

*Remark:* the target number is set in the Axis byte of the packet. The controller can hold up to 15 targets.

#### 4.4.14 GPS\_SetTargetUTM

<b>OpCode</b>	<b>0x0512</b>
<b>Data send format</b>	TargetUTM format (See section <a href="#">5.1.4</a> )
<b>Data send unit</b>	GPS Target
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Read target in UTM format. (target number between 1-15)

*Remark:* the target number is set in the Axis byte of the packet. The controller can hold up to 15 targets.



#### 4.4.15 GPS\_GoToTarget

<b>OpCode</b>	<b>0x0513</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send the system load to look and lock on the target.

*Remark:* the target number is set in the Axis byte of the packet. The controller can hold up to 15 targets.

#### 4.4.16 GPS\_ClearAllTargets

<b>OpCode</b>	<b>0x0514</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Clear all 15 targets of the controller.

## 4.5 IMU Commands

These commands retrieve data from the IMU unit.

In all of IMU commands, the axis byte in the packet is ignored (can be sent as 0x00).

### 4.5.1 IMU\_IsReadyImu

<b>OpCode</b>	<b>0x0601</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned integer (8-bit)
<b>Data return unit</b>	Boolean
<b>Description</b>	Check if the IMU is on and ready to be read.

*Remark:* This command returns 1 if the IMU unit is connected and communicating or 0 if not.

### 4.5.2 IMU\_GetRoll

<b>OpCode</b>	<b>0x0602</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the current Roll Value read by the IMU.

*Remark:* Roll can receive values between -180 to 180 degrees.

### 4.5.3 IMU\_GetPitch

<b>OpCode</b>	<b>0x0603</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the current Pitch Value read by the IMU.

*Remark:* Pitch can receive values between -180 to 180 degrees.

#### 4.5.4 IMU\_GetYaw

<b>OpCode</b>	0x0604
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	Degrees
<b>Description</b>	Get the current Yaw Value read by the IMU.

*Remark:* Yaw can receive values between 0 to 360 degrees.

## 4.6 Communication Commands

These messages are responsible on the communication between the PC (client's application) and the Controller.

In all of COM commands, the axis byte in the packet is ignored (can be sent as 0x00).

### 4.6.1 COM\_Reboot

<b>OpCode</b>	<b>0x0700</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Reboot the internal managing controller.

*Remark:* Allow the unit to reboot for about 20 seconds before trying to reconnect.

### 4.6.2 COM\_Connect

<b>OpCode</b>	<b>0x0702</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Starts Conversation with the internal controller.

*Remark:* This command activates both axes and allows the protocol commands to be processed. Movement mode is set to position mode, relative with speed set to 0 as default.

### 4.6.3 COM\_Disconnect

<b>OpCode</b>	<b>0x0703</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Terminate connection with the controller.

*Remark:* This command will stop internal controller and turn off the motors power supply. Movement mode is set to position mode, relative.

#### 4.6.4 COM\_SetComType

<b>OpCode</b>	<b>0x0719</b>
<b>Data send format</b>	Unsigned Integer (8-bit)
<b>Data send unit</b>	Communication type
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Change the communication type with the controller.

*Remark:* The communication types are:

- Ethernet - 0x01
- RS-232 - 0x02
- RS-422 - 0x03
- RS-485 - 0x04

The new communication type will be available after system reboot.

Make sure that your system supports the new communication type according to your order specification.

#### 4.6.5 COM\_GetPn

<b>OpCode</b>	<b>0x0C2D</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the Part Number of the system.

#### 4.6.6 COM\_GetSn

<b>OpCode</b>	<b>0x0C2F</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Int 32-bit
<b>Data return unit</b>	Number
<b>Description</b>	Get the Serial Number of the system.

#### 4.6.7 COM\_GetFw

<b>OpCode</b>	<b>0x0C4A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the Firmware revision of the controller.

#### 4.6.8 COM\_GetHw

<b>OpCode</b>	<b>0x0C4C</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Floating point 32-bit
<b>Data return unit</b>	None
<b>Description</b>	Get the Hardware revision of the controller.

## 4.7 IP Change Commands



The following section is relevant for Ethernet TCP communication type only.

Read all of the following commands carefully! Wrong use of these commands might result irreversible damage to the system. It is advisable to write down all the values before and after the change in case the system won't connect properly.

In all of IP commands, the axis byte in the packet is ignored (can be sent as 0x00).

Please be advised that certain commands change the IP address for the controller unit.

If you intentionally or by mistake use these commands, and hence changing the IP configuration, our guaranty will automatically expire, for issues related to IP change.

In this case you will be able to still send us the system for re-configuration, but this service is not covered under the guaranty, and you will be charged for the re-configuration and shipping costs.

By performing those actions you agree to these terms.

### 4.7.1 IP\_SetControllerIP

<b>OpCode</b>	0x070A
<b>Data send format</b>	4 byte hex value
<b>Data send unit</b>	IP Address
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send new IP address for the controller.

*Remark:* The data in this message is the new IP address for the controller in 4 bytes format.

*Example:* The address 192.168.10.13 will be sent as: 0xC0, 0xA8, 0x0A, 0x0D.

The new IP address will be activated after reboot.

### 4.7.2 IP\_GetControllerIP

<b>OpCode</b>	0x070D
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	4 byte hex value
<b>Data return unit</b>	IP Address
<b>Description</b>	Get the current IP value of the controller.

*Remark:* The IP address will return as a set of 4 bytes.

*Example:* The data 0xC0, 0xA8, 0x0A, 0x0D represents the address 192.168.10.13.

#### 4.7.3 IP\_SetControllerPort

<b>OpCode</b>	<b>0x070B</b>
<b>Data send format</b>	Unsigned Integer (16 bit).
<b>Data send unit</b>	Port number
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send new port for the controller.

*Remark:* The new port value will be activated after reboot.

#### 4.7.4 IP\_GetControllerPort

<b>OpCode</b>	<b>0x070E</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	None
<b>Description</b>	Get port value of the controller.

#### 4.7.5 IP\_SetControllerSubnetMask

<b>OpCode</b>	<b>0x071A</b>
<b>Data send format</b>	4 byte hex value
<b>Data send unit</b>	IP Address
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send new subnet mask for the controller.

*Remark:* The data in this message is the new subnet mask address for the controller in 4 bytes format.

*Example:* The address 192.168.10.13 will be sent as: 0xC0, 0xA8, 0x0A, 0x0D.

The new subnet mask will be activated after reboot.

#### 4.7.6 IP\_GetControllerSubnetMask

<b>OpCode</b>	<b>0x070B</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	4 byte hex value
<b>Data return unit</b>	IP Address
<b>Description</b>	Get the current subnet value of the controller.

*Remark:* The subnet mask will return as a set of 4 bytes.

*Example:* The data 0xC0, 0xA8, 0x0A, 0x0D represents the subnet 192.168.10.13.



#### 4.7.7 IP\_SaveIP

<b>OpCode</b>	<b>0x0710</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Save the current IP and port to controller memory.

*Remark:* After setting the desired values for the Controller IP and Port, this command will save the values to the memory of the controller so that the system will boot with these values each time. (Until changed and saved again).

There is no need to set all values at the same time, each value can be set separately.

It is advisable to read (get) all the values before sending the 'save' command in order to check everything got through to the controller.

After saving all values, a system reboot is needed for the changes to be updated.

IP change is permanent and does not need to be made each time you power on the system.

For any questions or misunderstanding regarding the IP address changing of the system, please contact Capture support team.

## 4.8 Stabilization commands

All STB commands except STB\_StabilizationOn and STB\_StabilizationOff require axis specification. When the stabilization mode is active, all Motor-Set data commands are prohibited. The controller will block these commands, and send invalid ACK byte (0xA6).

### 4.8.1 STB\_StabilizationOn

<b>OpCode</b>	<b>0x0800</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turn stabilization mechanism on.

*Remark:* When the stabilization mechanism is turned on, the system will point on its current position. A position sample is taken automatically when the command is sent. In other words, the stabilized position is the current position according to the IMU reading.

### 4.8.2 STB\_StabilizationOff

<b>OpCode</b>	<b>0x0801</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turn stabilization mechanism off.

*Remark:* After STB\_StabilizationOff command, the pedestal speed, acceleration and position is set to 0. Movement mode is position mode, relative.

### 4.8.3 STB\_StabMoveRel

<b>OpCode</b>	<b>0x0802</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send relative movement to the motor while the stabilization mechanism is active.

#### 4.8.4 STB\_StabMoveAbs

<b>OpCode</b>	<b>0x0803</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Send an absolute movement to the motor while the stabilization mechanism is active.

*Remark:* The angle is calculated according to the IMU reading (Yaw/Pitch).

#### 4.8.5 STB\_SetStabSpeed

<b>OpCode</b>	<b>0x0804</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees/Sec
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the speed of position movement under stabilization.

*Remark:* Sets the speed for position mode movement under stabilization. This command completes the position profile building along with the STB\_StabMoveAbs or STB\_StabMoveRel commands. The movement will be performed with the last value that was sent in STB\_SetStabSpeed. Speed must be positive value only.

Direction will be defined by the position value sent by STB\_StabMoveAbs or STB\_StabMoveRel.

#### 4.8.6 STB\_StabSpeedOn

<b>OpCode</b>	<b>0x0805</b>
<b>Data send format</b>	Floating point 32-bit
<b>Data send unit</b>	Degrees/Sec
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start moving in speed mode under stabilization.

*Remark:* This command will result continuous movement with the speed specified in the data of this message. Speed can be positive for CW Direction and negative for CCW direction.

#### 4.8.7 STB\_StabSpeedOff

<b>OpCode</b>	<b>0x0806</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Stop moving in speed mode under stabilization.

*Remark:* This command will terminate the movement started with STB\_StabSpeedOn command.

#### 4.8.8 STB Operation Notes

This section doesn't include an operation code of a specific command.

Here we explain some operation behaviours regarding the stabilization mechanism.

- 4.8.8.1 While stabilization is active (after activating opcode 0x0800) the controller enters to stabilization mode. During this mode the controller can receive only several 'Get' commands (that will be described in the next paragraph) and 'StabilizationOff' command (opcode 0x0801). In any case that the user sends a command that is not described here the controller will return an invalid command error: **0xA6**.

The commands that the user can send during stabilization are:

<b>OpCode</b>	<b>Command Name</b>
<b>0x0801</b>	STB_StabilizationOff
<b>0x0101 - 0x010A</b>	Chapter 4.1 'Get data commands'
<b>0x0E01 - 0x0E0B</b>	Chapter 4.10 'Error control commands'

## 4.9 Preset commands

Presets are pre-defined points that can be saved in the controller memory. Each system can store up to 15 points.

For all preset commands, the preset number should be sent in the *axis* field of the packet.

### 4.9.1 PRST\_GetPreset

<b>OpCode</b>	<b>0x0D00</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Number
<b>Return format</b>	Preset format (See section <a href="#">5.1.5</a> )
<b>Data return unit</b>	Preset
<b>Description</b>	Returns the selected preset values according to Preset format.

### 4.9.2 PRST\_SetPreset

<b>OpCode</b>	<b>0x0D01</b>
<b>Data send format</b>	Preset format (See section <a href="#">5.1.5</a> )
<b>Data send unit</b>	Preset
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets a new value to the selected preset.

### 4.9.3 PRST\_GoToPreset

<b>OpCode</b>	<b>0x0D02</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Drive the system axes to the selected preset.

*Remark:* the preset number should be sent at the axis number.

### 4.9.4 PRST\_ClearAll

<b>OpCode</b>	<b>0x0D03</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Clear all presets and sets them to 0.

#### 4.9.5 PRST\_GetPresetFlag

<b>OpCode</b>	<b>0x0D13</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-16
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Returns a 16 bit vector that indicates which preset is activated.

*Remark: bit 0 indicates preset 1 state, bit 1 indicates preset 2 state and so on.*

#### 4.9.6 PRST\_ClearSinglePreset

<b>OpCode</b>	<b>0x0D14</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Number
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Clears single preset value to 0.

*Remark: the preset number should be sent at the axis number.*


## 4.10 Error Control commands

Every 'Capture' system includes several status registers. Those registers describe the current status of each axis of the system.

The operation codes for the detailed motor registers are described in section [4.1.1](#). In this section we will describe the registers description.

### Warnings



In any case that error that marked with  keep showing please contact Capture-Systems support team in order to monitor those errors.






Most of the errors in the MER and DER registers will stop the motion. So in order to reset the errors (after your inspection) you can send the 'Reset faults' and the 'AxisOn' commands.




For each error you can read the detailed error string using the following opcodes (0x0E03-0x0E09). For each error type the controller can send several error messages. According to the returned error message the user can inspect it and operate the system according to it status.

### 4.10.1 ERR\_MotionErrorRegister

MER is a 16-bit status register. It groups together all of the errors conditions. Most of those errors conditions trigger the Fault status.

OpCode - 0x0101

Bit	Description	Notes
0	CAN bus error	0 – No CAN bus error 1 – CAN bus error Check your CAN bus wiring and communication protocol.
1	Short-circuit protection	0 – No short circuit error 1 – Short circuit error
2	Setup table status	0 – The drive has a valid setup table. 1 – The drive has an invalid setup table
3	Control error 	0 – No control error 1 – Control error Control error can occur if the motor doesn't reach the desired position or speed.
4	Communication error	0 – No serial communication error 1 – Serial communication error Please check your serial communication line with the drive.
5	Position sensor error 	0 – No error 1 - Error
6	Positive limit switch active	0 – LSP is not active 1 – LSP is active
7	Negative limit switch active	0 – LSN is not active 1 – LSN is active
8	Over current error 	0 - No over-current error 1 – Over-current error The system current consumption reached the protection limit.





9	I2T protection error 	0 – No drive or motor I2T error 1 – Drive or motor I2T error The system current consumption over time reached the protection limit. Please check if there are no mechanical limitations that prevent the system from moving.
10	Motor over temperature error 	0 – No motor over temperature error 1 – Drive motor temperature error. The motor is overheating. Make sure that your system supports your operation environment regarding the operation temperature.
11	Drive over temperature error 	0 – No drive over temperature error 1 – Drive over temperature error. The system is overheating. Make sure that your system supports your operation environment regarding the operation temperature.
12	Over voltage error	0 – No over voltage error 1 – Over voltage error Check the system power supply for both logic and motor and set it to the desired level.
13	Under voltage error	0 – No under voltage error 1 – Under voltage error Check the system power supply for both logic and motor.
14	Command error	0 – No command error 1 – Command error. The bit set in two cases: a. An UPD command is received during the AXISON command execution. MER (14) = 1 & SRL (7) = 0. b. A cancelable call is received while a TML function is active following a previous cancelable call. MET (14) = 1 & SRL (7) = 1.
15	Enable status of drive	0 – Drive enabled 1 – Drive disabled Check enable input state (in supported systems only)



#### 4.10.2 ERR\_DetailedErrorRegister

DER is a 16-bit status register. It groups together more errors conditions. Most of the errors conditions trigger the Fault status.

OpCode - 0x0102

Bit	Description	Notes
0	TML stack overflow	0 – No stack overflow. 1 – Stack overflow. Check your protocol implementation.
1	TML stack underflow	0 – No stack underflow. 1 – Stack underflow. Check your protocol implementation.
2	Homing not available 	0 – Not triggered. 1 – Triggered. If the homing sequence should work in your system you should contact Capture support team.
3	Function not available 	0 – Not triggered. 1 – Triggered. If a customized function should work in your system you should contact Capture support team.
4	UPD ignored	0 – Not triggered. 1 – Triggered. Message ignored. Please check the communication protocol.
5	Cancelable call ignored	0 – Not triggered. 1 – Triggered.
6	Software positive limit switch	0 – Not triggered. 1 – Triggered.
7	Software negative limit switch	0 – Not triggered. 1 – Triggered.
8	Invalid S-curve profile.	0 – Not triggered. 1 – Triggered. Resend your S-curve profile with different values.
9	UPD ignored for S-curve	0 – Not triggered. 1 – Triggered. The S-curve parameters are invalid.
10	Encoder broken wire 	0 – Not triggered. 1 – Triggered.
11	Motionless start fail 	0 – Not triggered. 1 – Triggered. For brushless motors only. Please contact Capture.
12	TML heartbeat ignored	0 – Not triggered. 1 – Triggered. Check your communication wires.
13	Self-check error	0 – Not triggered. 1 – Triggered.
14	Reserved	
15	Reserved	

### 4.10.3 ERR\_StatusRegisterHigh

SRH is the high part of a status register grouping together all the key status information concerning the drive/motor.

OpCode – 0x0103

Bit	Description	Notes
0	Drive initialization status	0 – Not performed. 1 – Performed.
1	Position trigger 1	0 – Not reached. 1 – Reached.
2	Position trigger 2	0 – Not reached. 1 – Reached.
3	Position trigger 3	0 – Not reached. 1 – Reached.
4	Position trigger 4	0 – Not reached. 1 – Reached.
5	Auto run mode status	0 – Disabled. 1 – Enabled.
6	Positive limit switch event/interrupt	0 – Not triggered. 1 – Triggered.
7	Negative limit switch event/interrupt	0 – Not triggered. 1 – Triggered.
8	Capture event/interrupt	0 – Not triggered. 1 – Event/interrupt triggered.
9	Target command	0 – Not reached. 1 – Target reached.
10	Motor I2T protection warning	0 – Motor I2T warning limit not reached. 1 – Motor I2T warning limit reached.
11	Drive I2T protection warning	0 – Drive I2T warning limit not reached. 1 – Drive I2T warning limit reached.
12	Reserved	
13	Gear ratio in electronic gearing mode	0 – Not reached. 1 – Reached.
14	Reference position in absolute electronic camming mode	0 – Not reached. 1 – Reached.
15	Fault status	0 – No fault 1 – Drive/motor in fault status

#### 4.10.4 ERR\_StatusRegisterLow

The status register (Low) includes the following data:  
OpCode - 0x0104

Bit	Description	Notes
7	Homing / Function call warning	0 – Not triggered. 1 – Warning triggered.
8	Homing / Function call active	0 – Homing not active. 1 – Homing is active.
10	Motion is complete	0 – In motion. 1 – Motion complete.
14	Event has occurred	0 – Not triggered. 1 – Event/interrupt triggered.
15	Axis is on	0 – Axis is Off. 1 – Axis is On.

#### 4.10.5 ERR\_MotionStatusRegister






MSR is a 16-bit status register, containing information about motion system status and some specific events like: control error condition, position wrap-around, limit switches, etc.  
OpCode - 0x0105

Bit	Description	Notes
0	Drive initialization status	0 – Not performed. 1 – Performed.
1	S-Curve update status	0 – S-curve updated successfully 1 – S-curve update denied.
2	Software protection status	0 – Not triggered. 1 – Triggered.
3	Control error status	0 – Not triggered. 1 – Triggered.
4	Reserved	
5	Position wrap-around	0 – Not triggered. 1 – Triggered.
6	Positive limit switch	0 – Not triggered. 1 – Triggered.
7	Negative limit switch	0 – Not triggered. 1 – Triggered.
8	Position capture	0 – Not triggered. 1 – Triggered.
9	Motion status	0 – In motion. 1 – Motion complete.
10	Contour	0 – Not in contour mode. 1 – In contour mode.
11	Events	0 – No event set, or programmed event not occurred yet. 1 – Last event reached.
12	Reserved	
13	Axis status	0 – Axis off. 1 – Axis on.
14	Event status	0 – Reset after update. 1 – Set for update.
15	Update the motion mode	0 – No update. 1 – Update.

#### 4.10.6 ERR\_CaptureMotorErrorRegister

CMER (Capture reduced Motor Error Register) is a 16-bit status register. It groups together the most relevant data from the MER, DER, SRL and SRH into single register.

OpCode – 0x0E0B

Bit	Description	Notes
0	Fault status	0 – No fault 1 – Drive/motor in fault status
1	Axis status	0 – Axis off. 1 – Axis on.
2	Motion is complete	0 – In motion. 1 – Motion complete.
3	Enable status of drive	0 – Drive enabled 1 – Drive disabled Check enable input state (in supported systems only)
4	Under voltage error	0 – No under voltage error 1 – Under voltage error Check the system power supply for both logic and motor.
5	Over voltage error	0 – No over voltage error 1 – Over voltage error Check the system power supply for both logic and motor and set it to the desired level.
6	I2T protection error 	0 – No drive or motor I2T error 1 – Drive or motor I2T error The system current consumption over time reached the protection limit. Please check if there are no mechanical limitations that prevent the system from moving.
7	Over current error 	0 – No over-current error 1 – Over-current error The system current consumption reached the protection limit.
8	Negative limit switch active	0 – LSN is not active 1 – LSN is active
9	Positive limit switch active	0 – LSP is not active 1 – LSP is active
10	Control error 	0 – No control error 1 – Control error The motor doesn't reach the desired position or speed.
11	Short-circuit protection 	0 – No short circuit error 1 – Short circuit error
12	Encoder broken wire 	0 – Not triggered. 1 – Triggered.
13	Software negative limit switch	0 – Not triggered. 1 – Triggered.
14	Software positive limit switch	0 – Not triggered. 1 – Triggered.

#### 4.10.7 ERR\_CaptureSystemRegister

<b>OpCode</b>	<b>0x0E01</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Unsigned Integer (16 bit).
<b>Data return unit</b>	16 bit vector
<b>Description</b>	Capture System Register is a 16-bit status register. It groups together data regarding the entire system status.

Bit	Description	Notes
<b>0</b>	Motor Error	0 – No error 1 – Error in one of the motors
<b>1</b>	System Error	0 – No Error. 1 – Error.
<b>2</b>	Base IMU error	0 – No Error. 1 – Error.
<b>3</b>	Load IMU error	0 – No Error. 1 – Error.
<b>4</b>	GPS communication error	0 – No Error. 1 – Error.
<b>5</b>	GPS position error	0 – No Error. 1 – Error.
<b>6</b>	GPS heading error	0 – No Error. 1 – Error.

#### 4.10.8 ERR\_ClearErrors

<b>OpCode</b>	<b>0x0E02</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Clears the CSR register

#### 4.10.9 ERR\_GetMotorErrorString

<b>OpCode</b>	<b>0x0E03</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the motor error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.10 ERR\_GetSystemErrorString

<b>OpCode</b>	<b>0x0E04</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the system error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.11 ERR\_GetLoadImuErrorString

<b>OpCode</b>	<b>0x0E05</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the load IMU error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.12 ERR\_GetBaseImuErrorString

<b>OpCode</b>	<b>0x0E06</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the base IMU error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.13 ERR\_GetGpsComErrorString

<b>OpCode</b>	<b>0x0E07</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the GPS communication error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.14 ERR\_GetGpsPosString

<b>OpCode</b>	<b>0x0E08</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the GPS position description

*Remark:* The error messages description is in the end of this section.

#### 4.10.15 ERR\_GetGpsHeadErrorString

<b>OpCode</b>	<b>0x0E09</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the GPS Head error description

*Remark:* The error messages description is in the end of this section.

#### 4.10.16 ERR\_GetProtocolErrorString

<b>OpCode</b>	<b>0x0E0A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	ASCII string
<b>Data return unit</b>	None
<b>Description</b>	Get the protocol error description

*Remark:* The error messages description is in the end of this section.



4.10.17 Error messages description:

OpCode	Description	Error message
<b>0x0E01</b>	Get CSR register	-
<b>0x0E02</b>	Clear errors	-
<b>0x0E03</b>	Get motor error string	- No communication with Pan motor driver - No communication with Tilt motor driver - No communication with Roll motor driver - No communication with Four motor driver - No communication with Five motor driver - No communication with Six motor driver
<b>0x0E04</b>	Get system error string	- General system error - Fail to access memory
<b>0x0E05</b>	Get load IMU error string	- No communication with Load IMU - Fail to sync with Load IMU
<b>0x0E06</b>	Get base IMU error string	- No communication with Base IMU - Fail to sync with Base IMU
<b>0x0E07</b>	Get GPS communication error string	- No communication with the GPS
<b>0x0E08</b>	Get GPS position error string	- The position of the GPS is not ready
<b>0x0E09</b>	Get GPS heading error string	- The heading of the GPS is not ready
<b>0x0E09</b>	Get protocol error string <b>Remark:</b> It is recommended to read this error after receiving an 'A6' NACK from the controller	- Axis not exist in the system - Axis 0 doesn't exist - Command not valid while stabilizing - Command not valid while homing - Invalid command for Manual system - Invalid command for single axis pedestal - IMU commands not available - GPS commands not available - Opcode not Recognized - Target no. out of range - Target not exist

## 4.11 Video Tracking commands

All VDT commands are available for Video tracking application only.

For systems that include two video channels (cam 1 and cam 2) the camera index should be sent in the *axis number* field.

For commands that are not related to the camera channels, the axis number should be 0.

### 4.11.1 VDT\_GetImageSize

<b>OpCode</b>	<b>0x0720</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-16
<b>Data return unit</b>	Pixels
<b>Description</b>	Returns the image size in pixels. First 2 bytes of the data related to the width and the last 2 bytes related to the height.
<b>Camera Index</b>	Required

### 4.11.2 VDT\_SetTrackMode

<b>OpCode</b>	<b>0x0721</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Tracking mode
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the tracking mode
<b>Camera Index</b>	Required

*Remark:* The supported tracking modes are:

No Tracking - 0x00

Drone Tracking mode - 0x01

Vehicle Tracking mode - 0x02

### 4.11.3 VDT\_GetTrackMode

<b>OpCode</b>	<b>0x0722</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-8
<b>Data return unit</b>	Tracking mode
<b>Description</b>	Gets the current tracking mode
<b>Camera Index</b>	Required

*Remark:* The supported tracking modes are:

No Tracking - 0x00

Drone Tracking mode - 0x01

Vehicle Tracking mode - 0x02

#### 4.11.4 VDT\_SetPtControlMode

<b>OpCode</b>	<b>0x0723</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Control mode
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the Pedestal movement master
<b>Camera Index</b>	Not Required

*Remark:* The pedestal can get movement commands from two instances, Joystick and C&C application. This command sets the master of the pedestal control.

Joystick mode - 0x00

Command and Control application mode - 0x01

#### 4.11.5 VDT\_GetPtControlMode

<b>OpCode</b>	<b>0x0724</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-8
<b>Data return unit</b>	Control mode
<b>Description</b>	Gets the current Pedestal movement master
<b>Camera Index</b>	Not Required

*Remark:* The pedestal can get movement commands from two instances, Joystick and C&C application. This command returns the current master of the pedestal control.

Joystick mode - 0x00

Command and Control application mode - 0x01

#### 4.11.6 VDT\_SetLatitude

<b>OpCode</b>	<b>0x0725</b>
<b>Data send format</b>	Double precision 64-bit
<b>Data send unit</b>	Degrees & Decimal minutes
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the current system latitude
<b>Camera Index</b>	Not Required

*Remark:* The value is positive for the upper side of the latitude lines (North) and negative for the lower side (South).

#### 4.11.7 VDT\_GetLatitude

<b>OpCode</b>	<b>0x0726</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Degrees & Decimal minutes
<b>Description</b>	Gets the current system latitude
<b>Camera Index</b>	Not Required

*Remark:* The value is positive for the upper side of the latitude lines (North) and negative for the lower side (South).

#### 4.11.8 VDT\_SetLongitude

<b>OpCode</b>	<b>0x0727</b>
<b>Data send format</b>	Double precision 64-bit
<b>Data send unit</b>	Degrees & Decimal minutes
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the current system longitude
<b>Camera Index</b>	Not Required

*Remark:* The value is positive for the East side of the latitude lines and negative for the West side.

Both Latitude and Longitude in the format of DDMM.mmmm  
DD: degrees, MM.mmmm: decimal minutes.

#### 4.11.9 VDT\_GetLongitude

<b>OpCode</b>	<b>0x0728</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Double precision 64-bit
<b>Data return unit</b>	Degrees & Decimal minutes
<b>Description</b>	Gets the current system longitude
<b>Camera Index</b>	Not Required

*Remark:* The value is positive for the East side of the latitude lines and negative for the West side.

Both Latitude and Longitude in the format of DDMM.mmmm  
DD: degrees, MM.mmmm: decimal minutes.

#### 4.11.10 VDT\_SetAltitude

<b>OpCode</b>	<b>0x0729</b>
<b>Data send format</b>	Float
<b>Data send unit</b>	Meters
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Sets the current system altitude in meters
<b>Camera Index</b>	Not Required

#### 4.11.11 VDT\_GetAltitude

<b>OpCode</b>	<b>0x072A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Float
<b>Data return unit</b>	Meters
<b>Description</b>	Gets the current system altitude in meters
<b>Camera Index</b>	Not Required

#### 4.11.12 VDT\_GetHeading

<b>OpCode</b>	<b>0x072A</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Float
<b>Data return unit</b>	Degrees
<b>Description</b>	Gets the current system heading
<b>Camera Index</b>	Not Required

*Remark:* The value is accurate only after a Northing process was done. Without the northing process this command will return 0.

#### 4.11.13 VDT\_GetTrackError

<b>OpCode</b>	<b>0x072C</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Target index (1-5)
<b>Return format</b>	Uint-32
<b>Data return unit</b>	Pixels
<b>Description</b>	Returns the tracking error from the boresight in pixels. First 2 bytes of the data related to the width and the last 2 bytes related to the height.
<b>Camera Index</b>	Required

#### 4.11.14 VDT\_VideoStabilization

OpCode	0x072D
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Video stabilization state
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turn on/off the video stabilization functionality
<b>Camera Index</b>	Required

*Remark:* The video stabilization states are:

Off – 0x00

On – 0x01

#### 4.11.15 VDT\_StartTrackXy

OpCode	0x072E
<b>Data send format</b>	Uint-16
<b>Data send unit</b>	Width and Height in pixels
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start tracking on selected pixel
<b>Camera Index</b>	Required

*Remark:* This commands start to track on an object that located in the selected pixel and draws the tracking square around it.

The first two bytes of the data refer to the object width location and the last 2 bytes refer to the object height location.

#### 4.11.16 VDT\_GoToLlaTarget

OpCode	0x072F
<b>Data send format</b>	Target LLA format (see section <a href="#">5.1.3</a> )
<b>Data send unit</b>	LLA Position
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Runs the system to the desired target
<b>Camera Index</b>	Not Required

#### 4.11.17 VDT\_SetHeading

<b>OpCode</b>	<b>0x0730</b>
<b>Data send format</b>	Float
<b>Data send unit</b>	Degrees
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Runs the system Heading value
<b>Camera Index</b>	Not Required

*Remark:* The heading value is valid after system northing.

#### 4.11.18 VDT\_GetTargetsList

<b>OpCode</b>	<b>0x0731</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Target list format (see section <a href="#">5.1.6</a> )
<b>Data return unit</b>	Target position in pixels
<b>Description</b>	Returns the targets list according to the list format.
<b>Camera Index</b>	Required

#### 4.11.19 VDT\_StartTrackTargetIndex

<b>OpCode</b>	<b>0x0732</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Target index
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Start tracking on a target according to its index
<b>Camera Index</b>	Required

#### 4.11.20 VDT\_StopTrack

<b>OpCode</b>	<b>0x0733</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Stops the tracking on the current target.
<b>Camera Index</b>	Required

*Remark:* This stop command should be sent to stop the current tracking (regardless on the tracking type: XY or index).

#### 4.11.21 VDT\_SetAcquisitionAssist

<b>OpCode</b>	<b>0x0734</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Acquisition assist state
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Assist initialization of the track box size and location. Impacts user designated targets in all tracking modes.
<b>Camera Index</b>	Required

*Remark:* The acquisition assist states are:

Off - 0x00

On - 0x01

#### 4.11.22 VDT\_GetAcquisitionAssist

<b>OpCode</b>	<b>0x0735</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-8
<b>Data return unit</b>	Acquisition assist state.
<b>Description</b>	Returns the acquisition assist state
<b>Camera Index</b>	Required

*Remark:* The acquisition assist states are:

Off - 0x00

On - 0x01

#### 4.11.23 VDT\_SetIntelligentAssist

<b>OpCode</b>	<b>0x0736</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Intelligent assist state.
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Tracker will look for turning tracks and if detected will attempt a reacquisition. The new track will be followed for a period of time before replacing the current track.
<b>Camera Index</b>	Required

*Remark:* Requires Acquisition Assist to be enabled

The intelligent assist states are:

Off - 0x00

On - 0x01



#### 4.11.24 VDT\_GetIntelligentAssist

<b>OpCode</b>	<b>0x0737</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	Uint-8
<b>Data return unit</b>	Intelligent assist state.
<b>Description</b>	Returns the intelligent assist state
<b>Camera Index</b>	Required

*Remark:* The intelligent assist states are:  
Off – 0x00  
On – 0x01

#### 4.11.25 VDT\_TargetDetectionOn

<b>OpCode</b>	<b>0x0738</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Detection mode
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Returns the intelligent assist state
<b>Camera Index</b>	Required

*Remark:* The supported detection modes are:  
No Detection – 0x00  
Drone Detection – 0x01  
Vehicle Detection - 0x02

#### 4.11.26 VDT\_TargetDetectionOff

<b>OpCode</b>	<b>0x0739</b>
<b>Data send format</b>	None
<b>Data send unit</b>	None
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Turns off the target detection mode
<b>Camera Index</b>	Required

#### 4.11.27 VDT\_SetCrossType

<b>OpCode</b>	<b>0x073A</b>
<b>Data send format</b>	Uint-8
<b>Data send unit</b>	Cross type
<b>Return format</b>	None
<b>Data return unit</b>	None
<b>Description</b>	Set the overlay cross type
<b>Camera Index</b>	Required

*Remark:* The supported cross types are:

No Cross - 0x00

Red Cross (+) - 0x01

Red Circle (o) - 0x02

Purple Square (■) - 0x03

#### 4.11.28 VDT Operation Notes

This section doesn't include an operation code of a specific command.

Here we explain some operation behaviours regarding the video tracking application.

4.11.28.1 While video tracking is active (after activating opcodes 0x072E or 0x0732) the controller is in video tracking mode. During this mode the controller can receive only several 'Get' commands (that will be described in the next paragraph) and 'StopTrack' command (opcode 0x0733). In any case that the user sends a command that is not described here the controller will return an invalid command error: **0xA6**.

The commands that the user can send during video tracking are:

<b>OpCode</b>	<b>Command Name</b>
<b>0x0733</b>	VDT_StopTrack
<b>0x0101 - 0x010A</b>	Chapter 4.1 'Get data commands'
<b>0x0E01 - 0x0E0B</b>	Chapter 4.10 'Error control commands'

4.11.28.2 Video tracking system can be assembled with one or two cameras.

Most of the video commands requires camera index (in case that we mentioned otherwise at the opcode description).

The camera index (1 or 2) should be sent in the *axis* field of the packet. In cases that the camera index isn't required the user should send 0 in the *axis* field.

## 5 Appendix

---

### 5.1 Data Formats

All data that is sent and received in the Capture protocol is in the topology of "Big Endian". This means that when sending the bytes of the desired format the MSB is first to arrive in the packet.

#### 5.1.1 Floating point 32-bit format example

The floating point number -45.87 in Hex presentation is 0xC2377AE1. Implementation with the protocol:

Data 1	Data 2	Data 3	Data 4
0XC2	0X37	0x7A	0xE1

The returned data from the controller is in the same order as mentioned above.

#### 5.1.2 Double precision 64-bit format example

The double precision number 12.6492487231 in Hex presentation is 0x40294C6A54215E57  
Implementation with the protocol:

Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7	Data 8
0x40	0x29	0x4C	0x6A	0x54	0x21	0x5E	0x57

The returned data from the controller is in the same order as mentioned above.

#### 5.1.3 Target packet format LLA

For the commands GetTargetLLA (0x050F) and SetTargetLLA (0x0510) the format of the data in the packet is in the following way:

Longitude [8 byte double]	Latitude [8 byte double]	Altitude[4 byte float]
---------------------------	--------------------------	------------------------

- Longitude – longitude of the target in decimal degrees format (DD.dddd).  
The value is positive for the East side of the longitude lines and negative for the West side.
- Latitude – latitude of the target in decimal degrees format (DD.dddd).  
The value is positive for the Northern side of the latitude lines and negative for the Southern side.
- Altitude – altitude of the target in meters.

Length byte of the packet in this case is 24 (0x18 in Hex).

\* Format is the same for sending and receiving.

\* Target number is specified in the Axis byte. The available targets numbers are 1-15.

### 5.1.4 Target packet format UTM

The Capture protocol uses standard UTM (WGS 84).

For commands GetTargetUTM (0x0511) and SetTargetUTM (0x0512) the format of the data in the packet is in the following way:

Easting [8 byte double]	Northing [8 byte double]	Zone[1 byte signed integer]	Altitude[4 byte float]
-------------------------	--------------------------	-----------------------------	------------------------

- Easting – easting of the target in meters (WGS84 standard).
- Northing – northing of the target in meters (WGS84 standard).
- Zone – The zone of the target: Positive value for Northern hemisphere and negative for Southern hemisphere.
- Altitude – altitude of the target in meters.

Length byte of the packet in this case is 25 (0x19 in Hex).

\* Format is the same for sending and receiving.

\* Target number is specified in the Axis byte. Targets numbers available are 1-15

### 5.1.5 Preset packet format

Each controller can hold position for up to 6 axes.

For commands GetPreset (0x0D00) and SetPreset (0x0D01) the format of the data in the packet is in the following way:

Name [16 bytes ASCII]	Azimuth [4 bytes float]	Elevation [4 bytes float]	Roll [4 bytes float]	X [4 bytes float]	Y [4 bytes float]	Z [4 bytes float]
-----------------------	-------------------------	---------------------------	----------------------	-------------------	-------------------	-------------------

- Name – The user can set a 16 bytes preset name that will be saved in the controller memory.
- Azimuth – Azimuth value of the Preset in degrees.
- Elevation – Elevation value of the Preset in degrees.
- Roll – Roll value of the Preset in degrees.
- X – X value of the Preset in degrees.
- Y – Y value of the Preset in degrees.
- Z – Z value of the Preset in degrees.

\* The values are absolute as read from the encoder position (Value read by the command MOT\_GetLoadPosition).

### 5.1.6 Targets list format

For GetTargetsList command (0x0732) the format of the data field in the packet is in the following way:

T <sub>1</sub> Width	T <sub>1</sub> Height	T <sub>2</sub> Width	T <sub>2</sub> Height	T <sub>3</sub> Width	T <sub>3</sub> Height	T <sub>4</sub> Width	T <sub>4</sub> Height	T <sub>5</sub> Width	T <sub>5</sub> Height
----------------------	-----------------------	----------------------	-----------------------	----------------------	-----------------------	----------------------	-----------------------	----------------------	-----------------------

- The system can hold up to 5 targets at once.
- Each value is represented Uint-16 [2 bytes], so the length of the data field is 20 bytes.
- In case that there are less than 5 detected targets the value of the relevant target will be (0, 0).

## 6 Communication settings

---

This section will discuss the different communication options and default values as well as how to change those values if needed.

There are several ways for the user to communicate with the controller:

- Ethernet TCP
- Serial RS-232
- Serial RS-422
- Serial RS-485

### 6.1 Default values for Ethernet:

	IP	PORT
<b>Controller</b>	192.168.10.120	4949
<b>PC</b>	No default	No default

*Table 4 - IP default settings*

The controller comes with a default IP and Port as mentioned in Table 4. Since the user can connect from different PC with different IP every time, the controller listens to the Ethernet line and whenever there is a TCP connect request, the controller opens an active connection via TCP to the PC. The Ethernet communication establishing process is as follows:

1. The user sends a TCP connect request to the controller.
2. The controller sends back a COM\_Connect message.
3. The user send COM\_Connect message.
4. The controller returns acknowledge (0x06) to the user.

Each time the user wishes to connect to the controller those steps should be performed. Connecting with a different PC is possible even when the program is running, the way to do that is to disconnect with the current PC and connect with the new one.

Controller IP can be changed for any new IP address. Please refer to section 4.7 for more information.

## 6.2 Default values for Serial ports:

All of the Serial lines have the same default values for the communication.

Baud Rate	Data bits	Parity bits	Stop bits
115200	8	None	1

*Table 5 – Serial default settings*

## 7 Packet send/receive Examples

---

This chapter focuses on giving the user some basic examples for each command type to be able to implement the protocol in an easier way.

There is a basic example written in C# for creating and using Ethernet TCP socket with some examples of sending and receiving of packets that can be downloaded from our website.

When sending commands to the controller there are several ways to receive feedback from the controller side signifying if the command was received successfully and executed correctly. These feedback messages are identical for all types of communication.

1. Sending wrong checksum:

When the user sends a packet with one of Capture protocol commands and the checksum byte doesn't match the content of the packet, the controller will send a single byte of 0xF6, this means that the controller tested the checksum byte and the test failed. The controller will not execute commands for packets with wrong checksum byte.

2. Error executing the command:

For all types of commands, when the controller encounters a problem and for some reason is not able to execute the command, it will send the user a single byte of 0xE6.

3. Sending invalid command:

When the system is in stabilization, tracking or scan modes, there are some restrictions for what MOT commands can be sent. Meaning that if there are commands that are prohibited to be sent when the controller is in one of these modes it will not execute them. The response from the controller for invalid commands is a single byte of 0xA6.

It is advised to check for response from the controller side, and if there is a single byte instead of a packet, the user should know that the command sent was invalid.

4. Pedestal unavailable:

In case that the motor controllers are unavailable for some reason, the controller will send to the user a single byte of 0x16

5. Video tracker unavailable:

For systems that includes video tracker only. In case that the video tracker is unavailable the controller will send the user a single byte of 0x76.

6. Acknowledge for valid command:

For commands that are valid and have correct checksum, the controller will send an ACK byte of 0x06.

## 7.1 MOT motion example

MOT commands are used for controlling the motors of the system. The following example will demonstrate a full motion profile commands that moves the Yaw axis at a certain angle.

- MOT\_SetTum
- MOT\_SetPositionRelative
- MOT\_SetAcceleration
- MOT\_SetSpeed
- MOT\_SendPosition
- MOT\_Update

After sending the following six commands, the specified motor will turn the Yaw axis.

MOT\_Update must come last in the sequence.

Each square stands for one byte in hex representation:

User send: *MOT\_SetTum without data*

0x50	0x54	0x04	0x00	0x01	0x01	0x3F	0x45
------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------

User send: *MOT\_SetPositionRelative without data*

0x50	0x54	0x04	0x00	0x01	0x01	0x38	0x3E
------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------

User send: *MOT\_SetAcceleration with data of 100 (Degrees/sec<sup>2</sup>)*

0x50	0x54		0x08	0x00	0x01	0x01	0x30	0x42	0xC8	0x00	0x00	0x44
------	------	--	------	------	------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------

User send: *MOT\_SetSpeed with data of 27.78(Degrees/sec)*

0x50	0x54	0x08	0x00	0x01	0x01	0x31	0x41	0xDE	0x3D	0x71	0x08
------	------	------	------	------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------



User send: *MOT\_SetPosition with data of 13.487(Degrees)*

0x50	0x54	0x08	0x00	0x01	0x01	0x32	0x41	0x57	0xCA	0xC1	0x5F
------	------	------	------	------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------

User send: *MOT\_Update without data*

0x50	0x54	0x04	0x00	0x01	0x01	0x34	0x3A
------	------	------	------	------	------	------	------

Controller answer: *Acknowledge*

0x06
------

## 7.2 Get data commands

This example will demonstrate the implementation of a single command that retrieve data from the controller.

Asking for the IMU Roll value from the system is made the following way:

User send: *IMU\_GetRoll (message without data)*

0x50	0x54	0x04	0x00	0x00	0x06	0x02	0x0C
------	------	------	------	------	------	------	------

Controller answer: *return packet with data (value of 30.184 degrees, 0x41F178D5 in hex)*

0x50	0x54	0x08	0x00	0x00	0x06	0x02	0x41	0xF1	0x78	0xD5	0x8F
------	------	------	------	------	------	------	------	------	------	------	------

After the controller sends the answer, it does not wait for some kind of acknowledge from the user side.  
Remark: reading IMU / GPS data from the controller is available only while the relevant sensor is installed.